

OPERATING INSTRUCTIONS

RB32-VSR FEATURES AND BENEFITS

1. Champion's RB32-VSR MiniBrute with variable speed & reverse motor is engineered for drilling holes and tapping threads.

- 2. The RB32-VSR features a 0-550 variable speed motor, which can be operated in both forward and reverse.
- 3. An optional tapping head unit is available for use with hand taps and spiral point taps. With Champion's 'quick change' tapping head, a variety of tap sizes #0 thru7/8" and 3/8" NPT pipe taps can be run utilizing the RB32-VSR.

TO ASSEMBLE / CHANGE THE RB32-TAPPER

- 1. The arbor and arbor support bracket must be removed to assemble the tapper.
- 2. Align the threaded hole in the tapper with the 1/2-20 thread spindle.
- 3. Turn clockwise to tighten.
- 4. To remove the tapper, use the 17mm wrench provided to hold the spindle nut inplace. Use the 7/16" wrench to hold the flats while turning counter clockwise to loosen.

USING THE RB32-TAPPER

- 1. Align the tapper collet with the hole on the bottom of the tapper.
- 2. Push up on one side of tapper, push in collet and let down sides of tapper to lockcollet into place.
- 3. Align tap with hole in center of the collet. Once aligned, push collet ring in, pushtap into collet and release center collet ring to lock tap into place.
- 4. Taps can be run at full speed after developing a comfortable technique. Switch to neutral prior to reversing taps. This will help prolong the life of the motor.
- 5. To remove, reverse steps.

RB32-VSR PANEL



RB32-VSR VERSATILITY



RB32-VSR WITH TAP





RB32-VSR WITH TWIST DRILL

RB32-VSR ADAPTOR OPTIONS











