



# 6" Upper Belt Sander Guard



## Installation Instructions:

1. **DISCONNECT MACHINE FROM POWER SOURCE.**
2. Locate belt guard in the lower position on the slide and tighten.
3. Hold guard assembly in place keeping guard level and 3/16" to 1/4" away from the belt.
4. Mark hole location.
5. Check for hardware clearance before drilling holes.
6. Drill 5/16" holes at marked locations.
7. Secure belt guard using supplied hardware.
8. Check clearance of all installed components before restoring power to the machine.

## **MODEL #13382**

### **FLEXBAR MACHINE CORPORATION**

250 GIBBS ROAD • ISLANDIA, NY 11749  
1-800-879-7575 • 631-582-8440 • FAX 631-582-8487  
sales@flexbar.com • www.flexbar.com